


marantz

Quick Start Guide

SACD  | Super Audio CD Player

Before you begin

What's in the box


Quick Start Guide




Safety instructions



Warranty
(for North America
model only)




CD Player



Power cord




Remote control
(RC004PMND)



2× R03/AAA batteries



Audio cable




Remote connector
cable



Required for setup

Amplifier



Speakers



Speaker cables



Optional

Computer




USB cable




Setup

1 Connect the player to your amplifier





2 Connect to power

Connect the power cord between the SACD 10 and a wall outlet.



3 Install batteries in the remote control




- Batteries can be taken out in reversed order.


4 Begin CD or Super Audio CD playback

- 1 Press S/ACD.
Switch the remote control operating mode to this unit.




- 2 Press the power (⏻) button.




- 3 Press  to open the disc tray.



- 4 Place CD in the disc tray.



- 5 Press  to start playback .



5 Listen to computer audio via USB-DAC

1 Install the Windows driver software

NOTE

The installation of the driver software is not necessary in the following cases.

- When you do not play back music from a PC using the USB-DAC of this unit.
- When using a macOS.

The driver software cannot be installed correctly if your PC is connected to the unit by a USB cable. If the unit and your computer are connected by a USB cable and the computer is switched on before installation, disconnect the USB and restart the computer.

Windows OS


System requirements : Windows 10 or Windows 11

- 1 Download the dedicated driver from the "Download" section of the SACD 10 page of the Marantz website (www.marantz.com) onto your PC.
- 2 Unzip the downloaded file, and double-click the exe file.




- 3 Install the driver.

- 1 Select the language to use for the installation.
- 2 Click "OK".



- 3 The wizard menu is displayed. Follow the instructions on the screen.
- 4 When the wizard is completed, click "Finish".




NOTE

Please see the FAQ at www.marantz.com if you experience any issues getting audio to play from your computer through the SACD 10. You may also want to check the support pages for audio player application.



2 Connect to PC or Mac



3 Listen to audio from PC or Mac


- 1 Press SACD.
Switch the remote control operating mode to this unit.
- 2 Power on.
- 3 Press USB-DAC to switch the input source to "USB-DAC".
- 4 Set the audio signal destination to this unit on the computer.




Windows OS

- 1 Open the "Control Panel" on the PC.
 - The control panel setting list is displayed.
- 2 Click the "Sound" icon.
 - The sound menu window is displayed.

- ③ Check that there is a checkmark next to “Default Device” under in “SACD 10” of the “Playback” tab.
 - When there is a checkmark for a different device, click “SACD 10” and “Set Default”.
- ④ Select “SACD 10” and click “Properties”.
 - The SACD 10 properties window is displayed.




- ⑤ Click the “Advanced” tab.
- ⑥ Select the sampling rate and bit rate to be applied to the D/A converter.
 - It is recommended that “2 channel, 32 bit, 192000 Hz (Studio Quality)” is selected.
- ⑦ Click “Apply”.
- ⑧ Click “Test”.
 - Check that audio from this unit is output from the PC.




macOS

System requirements: macOS 13 or 14

- ① Move the cursor to “Go” on the computer screen, and then click “Utilities”.
 - The utility list is displayed.
- ② Double-click “Audio MIDI Setup”.
 - The “Audio Devices” window is displayed.
- ③ Secondary click on “SACD 10”, and then check that “Use This Device For Sound Output” is checked.
 - If a different device is checked, select and “secondary click” on “SACD 10”, and then select “Use This Device For Sound Output”.



- ④ Select the “SACD 10” format.
 - It is normally recommended to set the format to “2 ch 32-bit Integer 384.0 kHz”.



- ⑤ Quit Audio MIDI Setup.

4 Use your favorite music applications on your PC/Mac to play audio through the SACD 10.

For high resolution audio playback you will need to obtain an advanced audio player software such as JRiver Media Center or Audirvana.

NOTE

Additional settings to output audio to the SACD 10 may have to be selected in your advanced audio player application. Please refer to the user's manual for your application.

Contact Marantz



1-800-654-6633

We hope you will enjoy your Marantz product for years to come. If you ever have any question or need any support, just get in touch via the free helpline. We are happy if you are happy.

In case you can't reach the helpline please check the support section on **www.marantz.com** for more information.

Owner's manual

Refer to the online manual for other functions, information and operation procedure details.

manuals.marantz.com/SACD10/NA/EN/





EN

FR

ES

marantz